Wireless Object Protection during opening hours



Piccolo Light® Technical specifications

Additional modules:

	Piccolo Light can be connected to detectors that fuint function in the second sec	unction as interface between an external sensor and the wireless system, e.g. an etween the screw terminals an alarm will be sent.
	Remote control to disconnect and connect Piccolo	Light.
Dimensions:	Central unit: 240x160x60 mm., 1500 grams. ultraSpot: 95x42x21 mm., 50 grams. combiSpot: 79x39x9mm., 25 grams. infraSpot: 79x39x9mm., 25 grams. inspot: 60x45x24mm., 60 grams.	
Battery lifetime:	3,6 V lithium battery for combiSpot and infraSpot. in combiSpot: approx. 5 years. in infraSpot: approx. 3 years.	
	3,6 V lithium battery for inSpot and ultraSpot. in inSpot: 3 years. in ultraSpot: 1 ¾ years	
Power supply:	Piccolo Light can be connected to a 230 VAC power controller (UPS) whereby the system will function a few minutes after power failure Windows 95, 32 Mbytes RAM, 800x600 monitor, USB-port or 1 free COM-port to connect the central unit.	
PC requirements:		
Cables:	Use serial cable (RS 232) or RS 232/USB converter From PC to alarm receiver: 24 AWG twisted leads.	
Temperature range:	Central unit: -10°C +55°C ultraSpot: -10°C +55°C combiSpot: -10°C +55°C infraSpot: -10°C +55°C inSpot: -10°C +55°C	
 <!--</td--><td> With Piccolo Light you can also: Forward alarm signals through the GSM-net as SMS or voice message. (requires a GSM-module). Forward alam signals as e-mail to PC. (requires a code from your telephone company). Couple Piccolo Light to the security service. Adjust detector sensivity and check battery voltage. Check signal strength on detectors and receiver conditions for RF-signal. Configurate external alarm signal on output-relays (e.g. siren, bell, lamp). Monitor correct detectorinstallation, disconnection of cable, jamming of RF-signal. </td><td> Some other advanges with Piccolo Light: Easy installation without use of cables. User friendly interface on Windows platform designed to install the system, receive and log all alarms. Many configuration and monitoring facilities from display, GSM-telephone or PC. Constant surveillance of wireless detectors which send out ok-signals at short intervals. Configuration of user names and user rights. Alarm transmitted in case of sabotage, power failure and jamming. 2 analog inputs, 8 digital inputs and 8 relay-outputs. </td>	 With Piccolo Light you can also: Forward alarm signals through the GSM-net as SMS or voice message. (requires a GSM-module). Forward alam signals as e-mail to PC. (requires a code from your telephone company). Couple Piccolo Light to the security service. Adjust detector sensivity and check battery voltage. Check signal strength on detectors and receiver conditions for RF-signal. Configurate external alarm signal on output-relays (e.g. siren, bell, lamp). Monitor correct detectorinstallation, disconnection of cable, jamming of RF-signal. 	 Some other advanges with Piccolo Light: Easy installation without use of cables. User friendly interface on Windows platform designed to install the system, receive and log all alarms. Many configuration and monitoring facilities from display, GSM-telephone or PC. Constant surveillance of wireless detectors which send out ok-signals at short intervals. Configuration of user names and user rights. Alarm transmitted in case of sabotage, power failure and jamming. 2 analog inputs, 8 digital inputs and 8 relay-outputs.

Profort as Gunnar Clausens Vej 3 DK- 8260 Viby J Phone +45 70233600 info@profort.com WWW.profort.com