


Personalarm  
Detektor m. aktiveringsknap



### Funktion:

Personalarmeren er en trådløs aktiv detektor, der kan sende to forskellige signaler afhængig af om der gives et kort (< 800 msek.) eller et langt tryk (> 800 msek.) Kort tryk fortolkes som ASSISTANCE og langt som OVERFALD. Dette kan ændres i opsætning af standardtekster.

Enheden forsynes med et internt batteri.

Detektoren benyttes f.eks. til at tilkalde hjælp, verificere en alarmtilstand, afstille en alarmtilstand, åbne og/eller lukke døre etc. I den centrale enhed beskrives hvilken funktion detektoren skal have.

Udgave med tilt-switch: ligger enheden vandret afgives en akustisk advarselstone i 20 sek. I dette tidsrum kan alarmen afstilles ved et tryk på knappen ellers afsendes alarm til enheden og tonen ophører.

### Anvendelse:

Detektoren bæres løs eller i tilhørende holder (klemme). Overfaldstrykket skal placeres så højt som muligt. Vær opmærksom på, at bæres detektoren bag metal eller armeret beton kan rækkevidden mindskes væsentligt.

### Service og vedligeholdelse:

Hver 6. måned bør det undersøges om detektoren kan aktiveres. Dette gøres ved at aktivere begge signaler.

Bagefter undersøges det, om der er kommet alarm fra detektoren på den centrale enhed.

Virker detektoren ikke, udskiftes batteriet. Hjælper dette ikke, udskiftes hele detektoren.

Detektorens interne batteri udskiftes ved at løsne skruen bag på detektoren. Batteriet løsnes forsigtig med en lille skruetrækker eller lign. Herefter isættes det nye batteri. Vær opmærksom på, at batteriet skal vendes rigtigt så polariseringen er korrekt. Vær ligeledes opmærksom på, at batteriet placeres, så det ikke kommer i klemme ved påmontering af låg.


### Specifikationer:

Størrelse:	58 x 35 x 15 mm
Vægt inkl. internt batteri:	25 g
Radius af trådløs signal:	Op til 300 m ved udendørs måling
Spændingsforsyning:	Batteri
Batterilevetid:	Ca. 5 år
Temperatur:	÷ 10° - + 55° Celcius

### Dele og tilbehør:

Detektor, 868MHz:	Profort nr. 004280
Internt batteri:	Profort nr. 004025
Brugsvejledning:	Profort nr. 104030

Personal alarm  
Detector with push button to activate



### Function:

The personal alarm acts as wireless detector, which can send two different signals depending on whether the activating button is pressed for a short (< 800 msec.) or long time (> 800 msec.). Short push is interpreted as ASSISTANCE and long as ATTACK. This can be changed by editing the standard texts.

The unit is supplied with an internal battery.

The detector can be used to call for help, or verify alarm, request cancelling of an alarm, open or close doors etc.  
The specific function should be programmed in the central alarm unit software.

Model with tilt switch: if the unit is vertically positioned an acoustical warning tone is transmitted for 20 sec. In this period of time the alarm can be reset by a push on the button, otherwise the alarm will be transmitted to the central unit and the tone will cease.

### Assembling:

The detector is carried in the pocket or fixed to a wall using a bracket. The detector should be worn/ fixed as high as possible (at least 1m). Please note that if the detector is activated behind metal or reinforced concrete the signal strength can be reduced considerably.

### Service and maintenance:

Every 6 month a check must be made whether or not the detector can be activated on both signals. Press the button first with a short press and afterwards with a long press.

Check if the alarms signals are registered in the central alarm unit.

If the detector doesn't work change the battery. If it still doesn't work, change the detector.

The detector's battery is exchanged by loosening the screw at the back of the detector. The battery is dismantled by loosening it carefully by using a small screwdriver or similar. Then mount a new battery. Please check the polarization (+ve & -ve) is correct. Also check the battery is positioned so that it is not squeezed when the cover is closed again.

### Specifications:

Dimension:	58 x 35 x 15 mm
Weight incl. internal battery:	25 g
Radius of wireless signal:	Up to 300 meters by exterior measurement
Power supply:	Battery
Battery life span:	Approx. 5 years
Temperature:	÷ 10° - + 55° Celsius

### Spare parts and accessories:

Detector, 868MHz:	Profort no. 004280
Internal battery:	Profort no. 004025
Manual:	Profort no. 104030